

PORTAVALIGIE LATERALE SPECIFICO - SPECIFIC TUBULAR SIDE-CASE HOLDER  
 PORTE-VALISES LATÉRAUX SPÉCIFIQUE - SPEZIFISCHES STAHLROHR-SEITENTRÄGER  
 PORTA-EQUIPAJE LATERAL ESPECÍFICO

# BMW F650GS 00/04

ISTRUZIONI DI MONTAGGIO - MOUNTING INSTRUCTIONS  
 INSTRUCCIONES DE MONTAJE - BAUANLEITUNG - INSTRUCCIONES DE MONTAJE

## ATTENZIONE - WARNING - ATTENTION

IL SUPPORTO "A" VA INSERITO TRA IL FIANCHETTO ED IL SILENZIATORE.

THE UPPER SUPPORT "A", MUST BE INSERTED BETWEEN SIDE PANEL AND THE SILENCER.

LE SUPPORT "A" DOIT ÊTRE INSÉRÉ ENTRE LE CÔTÉ PLASTIQUE ET LE POT.

