

KLR650 SU Rack Install
(picture on following page)

1. Do one side at a time. Remove seat and turn signals. Some turn signal wires may need to be lengthened. Do not do this unless you need to. Remove helmet lock. Check for fit on right side around exhaust.
2. Remove 8mm allen head bolt form luggage rack, and upper 8mm allen head bolt from passenger peg.
3. Now mount Su to side of bike, using supplied hardware. 35 mm bolt at passenger peg, 60 mm at luggage rack, 45 mm bolt at turn signal location. Turn signal tab to be mounted on inside of luggage rack with washer and nut on back side.
4. Do other side the same as the first.
5. Install bumper using 20 mm bolts and 8 mm nylocks, and 5/16 washers.
6. Relocate turn signals.

***Note:** the measurements used in the photos are for a pannier set-up going on a KLR-650 in a two up riding situation. Your position may vary.

Parts list:

- 2—8mm x 60 mm bolts
- 2—8mm x 60 mm bolts
- 8—8 mm nylock nuts
- 2 —Turn Signal Tabs
- 2—8 mm x 45 mm bolts
- 4—8 mm x 20 mm bolts
- 2—nylon spacers (to space out nut on turn signal)
- 10—5/16 Flat Washer

Call 800-444-8770 if you have any further questions.



#