



Thank you for purchasing Happy Trails products. Our products are proudly hand made in Boise Idaho, USA. If you have any questions or concerns about the installation of this product, please contact us directly at 1-800-444-8770 or e-mail installation@happy-trail.com.

Before you begin, place the bike on a hard level surface where you have room to work. Lay out the parts included in this kit and compare to the parts list on these instructions. If any parts or hardware are missing, contact us immediately at the number or email listed above.

Step 1:

Using a 6mm Allen wrench, remove the four bolts from the stock tail plate and set them aside. They will not be reused. Remove the tail plate from the bike.

Step 2:

Place the four 1/4" x 3/4" spacers over the mounting points on the bike and set the Happy Trails tail plate over them, lining up the countersunk holes with the mount points. Hand thread the 8x20mm flat head bolts included in the hardware kit through the spacers and into the mount points and tighten them down using a 5mm Allen wrench.

You're done! Time to ride!

Kit Contents:

- 1 - 22 KLR650 Skid Plate
- 1 - Instructions/Hardware

Required Tool List:

- 6mm Allen Wrench
- 5mm Allen Wrench

Hardware List:

- 4 - 8x20mm FH bolt
- 4 - 1/4" L x 3/4" W x .509" ID