

BMW F650 FUNDURO HWY PEGS & SKID PLATE HTPO-0-4 AND HTP1-1-4B



Thank you for purchasing Happy Trails products. Our products are proudly hand made in Boise Idaho, USA. If you have any questions or concerns about the installation of this product, please contact us directly at 1-800-444-8770 or e-mail installation@happy-trail.com.

Before you begin, place the bike on a hard level surface where you have room to work. Lay out the parts included in this kit and compare to the parts list on page 3 of these instructions. If any parts or hardware are missing, contact us immediately at the number or email listed above.

Bolt List:

- 2 M8x45 SHCS
- 4 M8x20 BHCS 12.9
- 1 M6x20 SHCS
- 1 M6 Flat Washer
- 1 M6 Lock Washer
- 8 M8 Flat Washers
- 2 M8 nylock nuts
- 4 KLR Skid Clamps

Hardware List:

Skid Plate
Highway Peg
Bolt kit
Instructions

Remove the factory skid plate. Place the new skid plate up to the frame, attach the skid plate the front bike frame using the two front bolts. Next, loosely attach the clamps. Once fitment as achieved, tighten the front bolts then the clamps. The clamp bolts will be hard to turn as the nuts are self locking. Please ensure the allen wrench is securely inserted into the bolt head to keep from stripping the head. Now you can place the foot peg where it is comfortable for you and drill and attach using the supplied bolts.

IMPORTANT!!!!

When installing Happy Trails racks, leave all bolt connections loose until the entire product is installed. Then go back and tighten all connections. We recommend the use of thread locking compound.



Note:

Foot pegs bolt to the Skid Plate.
Foot pegs bar is 19" long.



Happy Trails Products